

Elevator controller NVE-ELV200



The lift controller realizes centralized management by connecting indoor monitor, outdoor panel and Wiegand card reader. With easy operation and setting, this device meets users' diversified needs. The module has two operating modes. The module relays can be connected directly to the elevator buttons or to the PLC inputs. Lift controller can be set to master and slave types. In one lift controller unit, the Master Controller communicates with other slave lift controller by RS485.

Device type	Moduł windowy
Power supply input	12 V DC
PoE	18 V DC (NVE-SW200-7P), 48 V DC (802.3af)
Relays	16 x NO / NC
Port LAN	1 x 10M / 100M Ethernet
Card reader format	Interface Wiegand 26
Support	1 Elevator, 1 controller up to 16 floors maximum 128 floors